

FIG. 1 PRIOR ART




FIG. 2




FIG. 3A







FIG. 3B







FIG. 4A







FIG. 4B



70




FIG. 5A

75




FIG. 5B




FIG. 6A





FIG. 6B


70

FIG. 7A



75

FIG. 7B






FIG. 8A





FIG. 8B

FIG. 9A is a schematic diagram of a control panel for a printing system. The panel includes a power source (106) and an alarm (108). A switch (100) is used to select between different printing density correction Y (128) and printing density (130). The switch has four positions: 98, 100, 102, and 104. The 98 position is labeled "SELECT". The 100 position is labeled "SET UP". The 102 position is labeled "+". The 104 position is labeled "-".


70



FIG. 9A





75

FIG. 9B










FIG. 12B







FIG. 13A






FIG. 13B

